



**NOTES:**

- A. VISIT [WWW.SHARKSKINROOF.COM](http://WWW.SHARKSKINROOF.COM) TO REVIEW THE COMPLETE LINE OF ROOF UNDERLAYMENTS, APPLICATIONS AND INSTALLATION INSTRUCTIONS
- B. CLEAN MASONRY AND WIPE DOWN WITH WET SPONGE PRIOR TO INSTALLATION OF SHARKSKIN ULTRA SA
- C. INSTALL SHARKSKIN ULTRA SA IN ORDER AS SHOWN BY NUMBERS
- D. APPLY A BEAD OF CAULKING/SEALANT ALONG THE TOP EDGE OF SHARKSKIN ULTRA SA ON CHIMNEY
- E. INSTALL SHARKSKIN ULTRA SA TO FORM WATER SHEDDING LAPS
- F. INSTALL PROPER METAL COUNTER-FLASHING PER LOCAL CODES



**CHIMNEY**  
**SHARKSKIN ULTRA SA® - ALL WEATHER BARRIER**

<b>Drawing: SSUSA - 8</b>
<b>Scale: Not to Scale</b>
<b>Created: 02/24/2019</b>
<b>Supersedes: 07/23/2014</b>